ROBINSON HELICOPTER COMPANY

R44 MAINTENANCE MANUAL AND INSTRUCTIONS FOR CONTINUED AIRWORTHINESS RTR 460 VOLUME I

Production Certificate Number 424WE

Type Certificate Number H11NM



Robinson Helicopter Company Phone: (310) 539-0508 2901 Airport Drive Fax: (310) 539-5198

Torrance, California 90505-6115 Web: https://robinsonheli.com

United States of America

OFFICE HOURS

Monday through Friday, 7:30 a.m. to 4:30 p.m., Pacific Time. Lunch hour is 11:30 a.m. to 12:30 p.m.

HOLIDAYS

Please visit https://robinsonheli.com for a list of holidays and company shutdowns.

CUSTOMER SUPPORT AND SPARES ORDERS

Please visit https://robinsonheli.com for Customer Support contact information. Procure parts from any R44 Dealer or Service Center, or order directly from RHC Customer Service via email, fax, or phone.

PUBLICATIONS

Viewing RHC Maintenance Manuals (MMs) and Illustrated Parts Catalogs (IPCs) online at https://robinsonheli.com is recommended to ensure use of current data. Viewing MMs and IPCs offline via paper or digital download requires verification that the data is current. Refer to the online MM or IPC Revision Log for the list of current pages.

SUBSCRIPTION ORDER AND RENEWAL FORMS

Subscription order and renewal forms are located at https://robinsonheli.com.

WARRANTY INFORMATION

Helicopter and parts warranty information is located at https://robinsonheli.com.

CHAPTER LIST

		Introduction
Chapter	1	General
Chapter	2	Inspection
Chapter	3	Life-Limited Components
Chapter	4	Airframe
Chapter	5	Landing Gear
Chapter	6	Powerplant
Chapter	7	Drive Train
Chapter	8	Flight Controls
Chapter	9	Rotor Systems
Chapter	10	Rigging, Track and Balance
Chapter	11	Environment Control
Chapter	12	Fuel System
Chapter	13	Instruments
Chapter	14	Electrical and Avionics Systems
Chapter	15	Furnishings
Chapter	16	Dimensions and Descriptions
Chapter	17	Jacking and Hoisting
Chapter	18	Weight and Balance
Chapter	19	Ground Handling
Chapter	20	Parking and Storage
Chapter	21	Placards and Markings
Chapter	22	Servicing
Chapter	23	Standard Practices
Chapter	24	Autopilot
Chapter	25	Hydraulics
Chapter	26	Lights
Chapter	27	Doors and Windows
Chapter	28	Main Rotor
Chapter	29	Main Rotor Drive System
Chapter	30	Tail Rotor
Chapter	31	Tail Rotor Drive System
Chapter	32	Engine Controls
Chapter	33	Engine Oil System
Chapter	34	Police Version
Chapter	35	E.N.G. Version
Chapter	36	Cadet Version
Chapter	37	Electrical System
Chapter	38	Avionics
Chapter	39	Wiring Diagrams
Chapter	40	Special Tools
Chapter	41	Revision Log

Intentionally Blank

TECHNICAL PUBLICATIONS

RECOMMENDED CHANGE REPORT

Please direct recommended changes to RHC Technical Publications via the email address listed below, by phone, or by submitting a duplicate of this completed form by fax or mail. Please include or have available the information detailed in this form.

Recommended changes may include but are not limited to general comments, corrections, omitted information, or clarification of instructions.

Please send recommendations to:

Email: techpubs@robinsonheli.com Robinson Helicopter Company

Phone: (310) 539-0508 Attention: Technical Publications Fax: (310) 539-5198 2901 Airport Drive

Torrance, CA 90505-6115 United States of America

Date:	Publication:
Name:	Chapter:
Company:	Section:
Helicopter Model:	Page:
Serial Number:	Revision:
Phone:	-
Email:	-
COMMENTS:	

Intentionally Blank